

WIRELESS IOT INCLINOMETER SENSORS

SATEVIS[®] ALPHA-INC

WIRELESS IOT BI-AXIS INCLINOMETER

SCALABLE MEASURING RANGE

(±30° AND ±55°)



SATEVIS[®] ALPHA-INC

WIRELESS IOT TRI-AXIS INCLINOMETER

SCALABLE MEASURING RANGE

(±10° AND ±85°)



IOT INDOOR GATEWAY

IOT OUTDOOR GATEWAY

IOT SOLAR GATEWAY



QUICKSTART



Contents

1-TECHNICAL SUPPORT 02

2-VISUAL SYMBOLS DEFINITION 04

3-ACRONYMS AND ABBREVIATIONS 04

4-SATEVIS® IOT Alpha-INC 05

 4.1-Unbox your Device 05

 4.2-Device Overview 06

 4.2.1-Non-Contact Buttons and LEDS description 06

 4.2.2-How to Change the battery pack 07

 4.2.3-Interface for External Power supply 09

5-Device commissioning on your cloud software (Example with TTN) 10

 5.1-Reading the QR Code 10

 5.2-Change your Lora settings with Satevis® configurator software 10

 5.3-Register your Satevis® device on TTN 15

6-Sensor Installation 18

7-Sensor Zeroing 19

8-Checking Sensor Status on site 20

9-Where to find more Technical Information ? 21

1. TECHNICAL SUPPORT

For general contact, technical support, to report documentation errors and to order manuals, contact SATEVIS® Technical Support Center (STSC) at: tech-support@beanair.com

For detailed information about where you can buy the **BeanAir®** equipment/software or for recommendations on accessories and components visit:

www.satevis-systems.com

To register for product news and announcements or for product questions contact **SATEVIS®** Technical Support Center (STSC).

Our aim is to make this user manual as helpful as possible. Please keep us informed of your comments and suggestions for improvements. **SATEVIS®** appreciates feedback from the users.

Disclaimer

The information contained in this document is the proprietary information of **SATEVIS®**. The contents are confidential and any disclosure to persons other than the officers, employees, agents or subcontractors of the owner or licensee of this document, without the prior written consent of **BeanAir® Sensors**, is strictly prohibited.

BeanAir® Sensors makes every effort to ensure the quality of the information it makes available. Notwithstanding the foregoing, **BeanAir® Sensors** does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information.




BeanAir® Sensors disclaims any and all responsibility for the application of the devices characterized in this document, and notes that the application of the device must comply with the safety standards of the applicable country, and where applicable, with the relevant wiring rules.

BeanAir® Sensors reserves the right to make modifications, additions and deletions to this document due to typographical errors, inaccurate information, or improvements to programs and/or equipment at any time and without notice.

Such changes will, nevertheless be incorporated into new editions of this document. Copyright: Transmittal, reproduction, dissemination and/or editing of this document as well as utilization of its contents and communication thereof to others without express authorization are prohibited. Offenders will be held liable for payment of damages. All rights are reserved.

Copyright © SATEVIS® 2024

2. VISUAL SYMBOLS DEFINITION

Symbols	Definition
	Caution or Warning – Alerts the user with important information about SATEVIS® wireless IOT Sensors. if this information is not followed, the equipment /software may fail or malfunction
	Danger – This information MUST be followed if not you may damage the equipment permanently or bodily injury may occur.
	Tip or Information – Provides advice and suggestions that may be useful when installing SATEVIS Wireless IOT Sensors.

3. ACRONYMS AND ABBREVIATIONS

AES	Advanced Encryption Standard
CCA	Clear Channel Assessment
CSMA/CA	Carrier Sense Multiple Access/Collision Avoidance
GTS	Guaranteed Time-Slot
kSps	Kilo samples per second
LDCDA	Low duty cycle data acquisition
LLC	Logical Link Control
LQI	Link quality indicator
MAC	Media Access Control
PER	Packet error rate
POE	Power Over Ethernet
RF	Radio Frequency
SD	Secure Digital
UPS	Uninterruptible power supply
USB OTG	USB On The Go
WDAQ	Wireless DAQ
WSN	Wireless Sensor Networks

4. SATEVIS® ALPHA-INC

4.1.1 Unbox your SATEVIS® ALPHA-INC


Open the Device box



4.1.2 Drawing

Small Form Factor **Antenna 2dBi**

High Gain **Antenna 5dBi**



4.2 Device Overview

4.2.1 Non-Contact Buttons and LEDS description

The Device is provided with :

- 2 M8 cap
- M8 to USB cable
- 1 Magnet
- 1x 25cm Self-Fusing Tape
- High Gain Antenna 5dBi or Small Form Factor Antenna 2dBi

Use the Magnet to:

- Hello ! :Check sensor status
- Sensor Zeroing: Automatic Zero offset



4.2.2 How to Change the battery pack




Figure 1 and 2 : Unscrew the Lid and detach the battery by loosening the "Hook-and-loop strap".

PRODUCT OVERVIEW





Figure 3 : Remove the Battery-Pack



Figure 4 : You will find the "Battery-Remover" under the battery pack.



Figure 5: direct the "Battery-Pack Remover" towards the JST connector.



Figure 6 : Make sure the "battery-Remover" groove surrounds the connector.




Figure 7 : carefully lift the connector upwards, and remove the battery-pack connector.




Figure 8 : Insert a new battery-pack and close the device.




- Battery pack should be changed at your office in a dry environment, you will avoid to bring humidity inside Satevis® casing;
- Use only Lithium Thionyl Chloride non-rechargeable battery pack (max Voltage 11 V) , with reverse current protection diode for each individual cell;
- Never pull the battery connector from the connector, you will damage it.



Satevis® sensor can be powered from battery pack or USB power. If it's powered from USB , there is no need to keep the battery power ON .



4.2.3 Interface for External Power supply

M8 6pin Socket [MALE, A-CODING]- Pin assignment



Interface Name	M8 Pin assignation
5VDC Voltage	PIN 1
DATA -	PIN 2
DATA +	PIN 3
Not used	PIN 4
Not Used	PIN 5
GND	PIN 6

M8 6pin Plug (FEMALE, A-CODING)- Pin assignment




M8-6Pins Plug

Interface Name	5VDC Voltage	USB DATA -	USB DATA +	Not used	Not Used	GND
M8 Pin assignation	PIN 1	PIN 2	PIN 3	PIN 4	PIN 5	PIN 6
Wire Color [A-coding]	BROWN	WHITE	GREY	BLUE	GREEN	PINK

5. Device commissioning on your cloud software (Example with TTN)

5.1 Reading the QR Code



Scan the QR code to get the Device EUI and the default Join EUI. Join EUI can be changed from Satevis® LINK software. Antenna frequency is displayed on the antenna base



DEVICE EUI: 8C-1F-64-1D-70-00-0F-FF

5.2 Change your Lora settings with Satevis® LINK Software

1. Connect your Satevis® device to your PC/Laptop with USB /M8 cable adapter provided with it




2. Click on device manager, and check with communication port number is used by your Satevis® device.





In this example, it's the Communication port COM16


3. Launch your Satevis® communication software by clicking on start



4. Click on Lora Configuration to get Device EUI, Join EUI, App Root Key




Your Satevis® software displays connected confirming to connection to your satevis® device



Join/App EUI , App Root Key can be changed from this field

Device EUI can not be changed as it contains our Manufacturer ID

5. REGION CODE can be changed from here, make sure your Antenna is compatible with this frequency.




Two different antennas are proposed.

- 868MHz (frequency range 863-870MHz) antenna covers: EU868 [Europe], IN865[India], RU864 [Russia]
- 915MHz (Frequency Range 902-928MHz) antenna covers: US915 (North America), AU915 [Australia], KR920 [KOREA] and AS923[ASIA]

Join Mode is always OTAA as it's more secured than ABP.

AFTER VALIDATING YOUR NEW SETTINGS, YOUR DEVICE WILL RESTART WITH THESE NEW SETTINGS.

5.3 Register your Satevis® device on TTN



Click on Register end device

End device type

Input method ⓘ

- Select the end device in the LoRaWAN Device Repository
- Enter end device specifics manually

Click on Enter end device specs manually

Applications > lora-test-berlin > End devices

Register end device

Does your end device have a LoRaWAN[®] Device Identification QR Code? Scan it to speed up onboarding.

Scan end device QR code [Device registration help](#)

End device type

Input method

Select the end device in the LoRaWAN Device Repository

Enter end device specifics manually

Frequency plan *

Europe 863-870 MHz (SF9 for RX2 - recommended) | v

LoRaWAN version *

LoRaWAN Specification 1.0.2 | v

Regional Parameters version *

RP001 Regional Parameters 1.0.2 revision B | v

[Show advanced activation, LoRaWAN class and cluster settings](#) v

Select your frequency plan Lorawan version is 1.0.2

RP001 Regional Parameters 1.0.2 revision B

Provisioning information

JoinEUI *

01 01 01 01 01 51 55 67 ← Enter your Join EUI

This end device can be registered on the network

DevEUI *

00 80 E1 01 01 51 55 64 3/50 used ← Enter your Device EUI

AppKey *

46 9C 45 FE 63 17 50 45 B6 56 A8 64 70 90 B1 32 ← Enter your AppKey · you can use the default AppKey present on your satevis® device or click on generate to create a new one

End device ID *

eui-0080e10101515564

This value is automatically prefilled using the DevEUI

After registration

View registered end device

Register another end device of this type

← Register your end device

6. Sensor Installation

Satevis® device comes with a three-axis inclinometer, it can be easily mounted directly on both vertical and Horizontal structures



7. Sensor Zeroing




Figure 1 : Even if an angle bracket is used, it's sometimes difficult to bring a zero-offset on both X and Y axis [in the case if Z axis is on the same direction than Earth Gravity].. In some cases, the field operator can not spend too much time on this task.



Figure 2 : To enable the sensor zeroing function, hold the magnet on 'Sensor Zeroing" Label for more than 10s.



Figure 3 : The Activity LED blinks in blue, the sensor zeroing starts on both X and Y axis . When this process is done, the Activity led will blink again in blue color and transmits a data measurement to the Lorawan® network. If the sensor zeroing process is not done correctly [the device is moving] the Activity Led will blink in Red color.




Figure 4 : The Sensor-zeroing process can be also done remotely from the cloud software.

8. Checking Sensor Status on site



Figure 1 : After installing the **Alpha-Inc inclinometer**, the field operator can check at any moment if the sensor is working properly



Figure 2 : By Holding the magnet on the 'Hello!' label for more than 10s, the sensor wakes-up and transmits to the Lorawan network the data measurement followed by the system diagnostic [battery status and network quality].



Figure 3 : The Activity Led blinks in **green color**, confirming that a data measurement is transmitted to the Lorawan network.



Figure 4 : The field operator can check on **Satevis® Cloud software** (or a third-party cloud software) if his sensor is working properly.

9. Where to find more Technical Information ?

- For more technical literature, please visit our White Paper Page: <https://www.satevis-systems.com/white-paper.html>
- Please refer to the SATEVIS® Alpha-INC-Kompakt user manual section for more information <https://www.satevis-systems.com/files/User-Manual-SATEVIS-LORA-ALPHA-INC-MR-PS.pdf>
- Facing technical problems ? Contact our technical support team at : tech-support@beanair.com





Buchholzer Straße 65,
13156 Berlin, Germany



www.satevis-systems.com



info@BeanAir.com



+493066405051